

Party Plus Rentals

E-Z UP CANOPY INSTRUCTIONS

1. Place E-Z UP in center of area to be sheltered. Remove cover. With partner on opposite side, grasp two outer legs, lift off ground and step backwards, stopping at full arms length.



2a. (For a 10 X 10 Shelter) On opposite sides, grasp the bottom of the “diamond” formed by the poles. Lift up and step backwards until shelter is fully opened, being careful not to pinch fingers.

2b. (For a 10 X 20 Shelter) With partner, move to middle leg of 20’ side. Grasp bottom of “diamond” formed by the poles. Lift up and step backwards at the same time until shelter is fully opened, being careful not to pinch fingers at end of truss.

3. Engage the auto slider at each corner by pushing up with one hand while holding down top of leg with the other hand. Snap button will engage in hole. Repeat on all other legs.



4. Lift two adjacent outer legs up and pull out the inner legs until snap button locks. Repeat on all legs. Raise or level the shelter using adjustment holes found near bottom of each outer leg.

IMPORTANT INFORMATION

1. Always stake or weigh down your E-Z UP Instant Shelter. Take E-Z UP down in threat of heavy winds.
2. Let the E-Z UP top and frame dry completely before closing or storing.
3. The E-Z UP is designed as a temporary shelter. We do not recommend leaving it up for extended periods. Do not leave E-Z UP unattended.